



Reliable Connections™

B-101 Drilling & Tapping Machine

Important Notice

When using this tool for tapping any plastic pipe, specific instructions and recommendations of the plastic pipe manufacturer must be followed. Due to the many types of plastic pipe sold, Mueller Co. assumes no responsibility for performance of any threaded connection in plastic pipe.

After completing the cut, **never** turn the boring bar counter-clockwise as doing so could disconnect the cutting tool leaving it stuck in the pipe or dropping it into the pipe. If the cutting tool cannot be removed by simply **pulling straight up** on the boring bar, use the machine yoke to pull it out by locking it to the thrust collar and turning the feed yoke counter-clockwise while continuing to turn the boring bar clockwise.

Phone: (800) 423-1323

By deviating from the above listed instructions, you will void any product warranty and release Mueller Co. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit www.muellercompany.com.

© 2016 Mueller Co., LLC. All rights reserved.

Form 12526 03/16