

# GATE VALVE ORDERING INSTRUCTIONS



# 10.53

Shaded area indicates change Rev. 4-14

---

## To order Gate Valves specify:

### Quantity

If more than one size, specify quantity of each

---

### Size

Nominal size of valve

---

### Catalog number

---

### Special catalog number suffix

See chart at bottom of page 10.40 if gearing, grease cases, bypass valves or position indicators are required. The appropriate suffix number is added to the base catalog number.

---

### Direction of opening

Specify open left (counter-clockwise) or open right (clockwise). Wrench nuts on valves that open to the right are painted red for identification purposes.

---

### Method of operation

N.R.S. valves are available with either a 2" square wrench nut or a handwheel. Handwheels are standard on flanged x flanged and thread x thread valves; all other NRS\* valves have a 2" square wrench nut as standard. Outside screw and yoke type valves are available with handwheel only. When ordering NRS valves, specify wrench nut or handwheel.

\* 30"-54" resilient wedge and double-disc gate valves must be ordered with actuator.

---

### Special Requirements

Contact MUELLER Customer Service Center with special requirements such as special paints or coatings, low zinc bronze stems, stainless steel fasteners etc.

---

### Gate Valve Repair Parts

To order repair parts specify size of valve, direction of opening, year date on body, part number, catalog number of valve if known, and type of ends if ordering body.

---