

Accessories, Mechanical Joint .....	10.2, 10.28	Brass Lever Handle .....	7.19, 7.20, 8D.15
Adapters, Curb Box .....	7.32	Brass Tees .....	6.24-6.25
Adapters, Drilling Machine.....	3.5, 3.13, 3.21	Bronze Gate Valves.....	7.19
Adapter, Power Operator.....	3.23	Bushing, Brass .....	6.34
Adapter Nipples, D-5™.....	2.11	Bushing, Water Meter.....	8E.4
“ ”, E-5™.....	2.6	Butterfly Valves.....	11.3 - 11.16
“ ”, Mega-Cut™.....	2.17	By-Pass Clean-out Tap, A-3™ Machine .....	1.16
“ ”, PL-2™.....	2.23	By-Pass, NRS for Gate Valves .....	10.44, 10.46, 10.48
Adjustable Seat Wrench for		By-Pass Kit, O-Ring Type, B-101™ Machine .....	1.9
Fire Hydrant.....	9.22, 9.25, 9.27	Cap, Brass.....	5.15, 6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Adjustable Copper Meter Yoke.....	8A.29, 30	Cast Iron Meter Boxes.....	8C.1-8C.4
Air Power Operator.....	1.25, 1.27, 2.13, 3.23, 3.24	Centurion® Fire Hydrants.....	9.6 - 9.9, 9.12, 9.13, 9.16, 9.17
Angle Meter Check Valves .....	8B.2, 8B.3, 8B.4, 8D.14	Chain, Flat Link.....	1.8, 1.11, 1.16, 1.21
Angle Meter Stops/Valves .....		Chain Hook.....	1.8, 1.9, 1.17, 1.22, 1.24
8DB.2, 8B.3, 8B.4, 8D.1, 8D.2, 8D.11, 8D.12		Chain, Round Link.....	1.8, 1.23
Arch Pattern Curb Boxes.....	7.25, 7.26, 7.27, 7.28	Chain Spreader .....	1.8, 1.16, 1.21, 1.23
Auger, Curb Box Clean-out.....	7.31	Check Valves, AWWA.....	13.2-13.14
AquaGrip .....	9.8, 9.9, 10.24 - 10.29	“ ”, Dual, Angle Meter... 8A.1 - 8A.30, 8B.D, 8D.14	
AWWA Check Valves.....	13.2, 13.4, 13.6, 13.8, 13.10, 13.13	“ ”, Dual, In-Line, Brass.....	8D.13
AWWA Fire Hydrants .....		“ ”, Dual, Meter Box .....	8C.3, 8C.4, 8C.7
.....	9.4, 9.6, 9.8, 9.12, 9.16, 9.20, 9.24, 9.26	“ ”, Top Entry Vertical .....	8A.1-8A.22, 8B.4, 8D.12
AWWA Gate Valves, NRS .....		Clamps, Pipe Repair.....	15.1-15.28
10.4, 10.6, 10.8, 10.10, 10.12, 10.13A, 10.13C, 10.14, 10.16,		Clamps, Service (see “Service Saddles”).....	4.6-4.13
10.18, 10.20, 10.22, 10.24, 10.26, 10.28, 10.30, 10.32, 10.34,		Clean-out Tap, By-Pass, A-3™ Machine .....	1.16
10.36, 10.38, 10.40, 10.41, 10.42, 10.44-10.49, 10.53-10.54		Clevis, Power.....	1.8, 16
AWWA Resilient Seat Gate Valves		Combined Drills & Taps	
NRS (parts only).....	10.54	A-3™ Machine.....	1.12, 13
AWWA Resilient Seat Gate Valves OS&Y		B-101™ Machine.....	1.4, 5
(parts only) .....	10.54	H-W™ Machine .....	1.23
AWWA Resilient Wedge Cut-In Valves .....	12.24, 12.25	J™ Machine .....	1.20
AWWA Resilient Wedge Gate Valves.....	10.4 - 10.43	Combined Shell Cutters & Taps	
AWWA Tapping Valves .....	12.12 - 12.15, 12.18 - 12.20	A-3 Machine .....	1.13
Ball Valves, Angle Meter.....	8B.2, 8B.3, 8D.1, 8D.2	B-101 Machine .....	1.5
Ball Valves, Corporation .....	5.4, 5.5, 5.6, 6A.2	Compression Connections 110® (see also “Pack Joint Connections”)	
Ball Valves, Curb .....	6A.3, 6A.4, 7.5 - 7.10	Branches .....	6.26, 6.27, 6.29, 6.30
Ball Valves, Service .....	8D.3	Corporation Valve.....	5.4, 5.7, 5.8
Ball Valves, Straight.....	8D.4, 8D.5	Curb Valve.....	7.5 - 7.7, 7.11, 7.16, 7.18
Barrel Extension Sections Fire Hydrants.....	9.11, 15, 19	Fitting.....	6A.5
Basement Copper Meter Yokes.....	8A.25	Meter Valve .....	8D.1, 8D.2, 8D.4, 8D.5, 8D.9 - 8D.12
Basic Equipment, Inserting Valve .....	12.22	Meter Yoke .....	8A.2, 8A.4, 8A.15
Bell Joint Repair Clamps .....	15.4	Connections, Branch .....	6.26, 6.27, 6.29, 6.30
Belt, Web .....	1.8, 16	Connections, Compression, Mueller 110®	
Bevel Gearing, Gate Valve .....		..... (See “Compression Connections”)	
10.15, 10.17, 10.19, 10.21, 10.23, 10.44, 10.46, 10.48, 10.50		Connections, Compression, Pack Joint	
Beveling Tool, Pipe .....	6.18, 7.24, 8A.52, 8D.18	..... (See “Pack Joint Connections”)	
Boxes, Curb.....	7.25-7.30	Connections, Copper Service	
“ ”, Curb—Arch Pattern.....	7.25-7.28	..... (See “Copper Service Connections”)	
“ ”, Curb—Minneapolis.....	7.29-7.30	Connections, Mueller Insta-Tite®	
Branches, “U” Type.....	6.26, 6.27, 6.28	..... (See “Insta-Tite® Connections”)	
Branches, “Y” Type.....	6.29-6.30	Connections, Multi Purpose	
Brass Angle Lever Handles .....	7.20, 8D.15	..... (See “Multi Purpose Connections”)	
Brass Cap.....	5.15, 6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16	Copper Disc.....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Brass Hammer.....	5.15, 6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16	Copper Flare Nuts .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Brass Meter Idler .....	8E.4	Copper Meter Yokes .....	8A.1 - 8A.35
Brass Plugs .....	6.34	Copper Service Connections.....	
Brass Sleeve, Fire Hydrant.....	9.10, 9.14, 9.18	.....	6.4 - 6.7, 6.11, 6.15, 6.17, 6.21, 6.22

Copper Service Tees .....	6.24, 6.25	“ ” , Operating Wrench .....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27
Copper Service Tools .....	6.8, 6A.8, 7.23, 7.24, 8B.8, 8C.7, 8D.16	“ ” , Repair Kits .....	9.11, 9.15, 9.19
Corner Copper Meter Yokes .....	8A.24	“ ” , Seat Wrench .....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27
Corporation Stops/Valves .....	5.4-5.11	Fittings, Service .....	
Corporation Stop Wrench .....	5.12-5.16	Copper Flare .....	6.4-6.8
Couplings, Corporation Stop/Valve .....		Compression Connection 110® .....	6.9-6.11
Copper Flare .....	6.4-6.8	Hose Clamp Ribbed .....	6.21
Compression Connection 110® .....	6.9-6.11	Insta-Tite® .....	6.17
Hose Clamp Ribbed .....	6.21	I.P. Thread Copper Flare .....	6.22
Insta-Tite® .....	6.17	Pack Joint .....	6.13-6.16
I.P. Thread Copper Flare .....	6.22	Flaring Tools .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Pack Joint .....	6.13-6.16	Flaring Tools, Drilled .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Couplings, Meter Yoke .....	8A.48, 49	Flat Chain Hook .....	1.8
Couplings, Water Meter .....	6A.5, 6A.6, 8E.1, 8E.2	Flat Link Chain, A-3™ Machine .....	1.16
Covers, Meter Box .....	8E.3	“ ” “ ” , B-101™ Machine .....	1.8
Crosses, Tapping .....	12.8-12.9	Flexible Copper Meter Yokes .....	8A.23, 28
Curb Box Adapter .....	7.32	“ ” “ ” — Relocator Type .....	8A.26, 28
Curb Box Clean-out Auger .....	7.31	Gasket Material for Repair Clamps .....	15.24
Curb Box Foot Pieces .....	7.25	Gaskets .....	
Curb Box Lids .....	7.26, 7.28, 7.30	Compression Connection 110® .....	6A.7, 6.12, 6.31, 8A.50, 8B.9, 8C.8, 8D.17
Curb Box, Oriseal® .....	7.25, 7.27, 7.29	Pack Joint Connection .....	6A.7, 6.16, 8A.51, 8B.9, 8C.8, 8D.18
Curb Box Repair Lids .....	7.32	Gate Valves, AWWA Double Disc .....	10.44-10.48, 10.51
Curb Box Shut-off Keys and Rods .....	7.31	Gate Valves, AWWA Resilient Seat (parts only) .....	10.54
Curb Box Sleeves .....	7.32	Gate Valves, AWWA Resilient Wedge .....	10.4-10.43
Curb Boxes .....	7.25-7.32	Gearing, Spur with Grease Case .....	10.50
Curb Stops/Valves .....	7.5-7.20	Grease Cases for Gate Valve Gearing .....	10.53
Cut-in Sleeves .....	12.23	Gripper Rings, Mueller Insta-Tite® Connection .....	6.18, 7.24, 8A.52
Cut-in Valves .....	12.24, 26	Holders, Drill .....	2.4, 2.5, 2.9, 2.10, 2.15, 2.16
Cutter Hubs .....	3.4, 3.12, 3.13	Horizontal Inlet and Outlet Copper Meter Yokes .....	8A.1 - 8A.9, 8A.23, 8A.26 - 8A.30, 8A.32, 8A.33
Disc, Copper .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16	Hose Clamps .....	6.21
Drilled Flaring Tool .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16	Hubs, Cutter .....	3.4, 3.12, 3.13
Drilling Machines, Large .....	3.1-3.24	Hydrant Defender .....	9A.1
Drilling Machines, Small .....	2.1-2.24	Hydrant Hold-Down Nut .....	9A.8
Drilling & Tapping Machines .....	1.3, 1.11, 1.19	Hydrant Security .....	9A.1-9A.5
Drill Holders .....	2.4, 2.5, 2.9, 2.10, 2.15, 2.16	Inserting Tools, A-3™ Machine .....	1.14
Drills .....	2.4, 2.9, 2.15	“ ” , B-101™ Machine .....	1.6
Drills, Pilot, Combined Shell Cutter & Tap .....	1.5, 1.13, 2.5, 2.10, 2.16, 3.4, 3.12, 3.21	Inserting Valve .....	12.22
Dual Check Valves .....	8A.1 - 8A.30, 8B.5, 8D.14, 8D.15	Inserting Valve, Basic Equipment .....	12.22
Dual Check Valves for Cast Iron Meters .....	8C.7	Insulated Products .....	
Electric Power Operators .....	1.26, 1.27, 2.13	Corporation Ball Valves .....	6A.2
Equipment, Basic, Inserting Valve .....	12.22	Curb Valves .....	6A.3-6A.4
Equipment, Drilling Machines Large .....	3.3 - 3.5, 3.11 - 3.13, 3.20, 3.21	Meter Couplings .....	6A.6
Expansion Handwheel .....	8B.1	Product Accessories .....	6A.7
Extracting Tools, A-3™ Machine .....	1.14	Service Fittings .....	6A.5
“ ” , B-101™ Machine .....	1.6	Insta-Tite® Connections .....	6.17
Fire Hydrants .....	9.3-9.30	Iron Meter Yokes .....	8B.1
Fire Hydrants, Lubricating Oil .....	9.10, 9.14, 9.18		
“ ” , Nozzle Lock Tool .....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27		
“ ” , Nozzle Wrench .....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27		

Iron Meter Yoke (Section 8B)—	
Angle Meter Ball Valves .....	8B.2, 8B.3
Angle Meter Check Valves .....	8B.5
Couplings .....	8B.6, 8B.7
Expansion Handwheel.....	8B.1
Lock Nuts .....	8B.1
Straight Meter Valves .....	8B.2, 8B.4
Washers .....	8B.9
Joint Repair Clamps .....	15.23
Keys, Curb Box.....	7.31
Keys, Meter Box .....	8C.7, 8E.3, 8F.12
Keys, Pentagon .....	8E.3
Kits, Fire Hydrant Repair .....	9.11, 9.15, 9.19
Large Drilling Machines .....	3.3, 11
Lever Handles, Angle .....	7.20, 8D.15
"    ", Straight.....	7.19, 7.20 8D.15
Lids, Curb Box.....	7.26, 28, 30
Lids Curb Box Repair .....	7.32
Liners.....	
5.12, 5.14, 5.16, 6.12, 6.16, 6.31, 6.32, 6.33, 6A.7, 7.21, 7.22, 8A.50, 8A.51, 8B.9, 8C.8, 8D.17	
Lockwing Sealing Device.....	8E.4
Lockwing Valves .....	8D.1 - 8D.9, 8D.11, 8D.12
Lubricant, Fire Hydrant.....	9.10, 9.14, 9.18
Machine Adapter Nipples D-5™ .....	2.11
"    "    "    E-5™ .....	2.6
"    "    "    Mega-Cu™ .....	2.17
"    "    "    PL-2™ .....	2.23
"    "    "    Tru-Cut™ .....	2.20
Machines, Large Drilling C1-36-99002.....	3.11
"    "    "    CL-12™ .....	3.3
Machines, Tapping A-3™ .....	1.11
"    "    "    B-101™ .....	1.3
"    "    "    J™ .....	1.19
"    "    "    H-W™ (parts only) .....	1.24
Mega-Cut™ Machine.....	2.14
Meter Box, Cast Iron.....	8C.1- 8C.4
Meter Box Covers.....	8E.3
Meter Box Cover Keys.....	8C.7, 8E.3, 8F.12
Meter Bushing .....	8E.4
Meter Coupling Washers .....	8E.4
Meter Couplings .....	6A.5, 6A.6, 8E.1, 8E.2
Meter Resettters .....	8A.44 - 8A.47
Meter Setters .....	8A.36 - 8A.43
Meter Stops/Valves, Angle.. 8D.1 - 8D.3, 8D.11, 8D.12, 8D.14	
Meter Stops/Valves, Straight .....	8D.4, 8D.5, 8D.9
Meter Valve Locking Device .....	8E.4
Meter Yokes, Copper.....	8A.1 — 8A.35
Minneapolis Pattern Curb Boxes .....	7.29-7.30
Minneapolis Pattern Curb Valves ...7.5 - 7.9, 7.11 - 7.15, 7.17	
Modern Centurion® Fire Hydrants.....	9.4, 9.12 - 9.15
Motor, Air .....	1.25, 2.13, 3.23
Multi Purpose Connections.....	8A.48, 8A.49
Needle Slot Position Indicator .....	10.46
Nipples, Machine Adapter.....	2.6, 2.11, 2.17, 2.20, 2.23
Nitrile Gaskets .....	15.24
Non-Rising Stem Gate Valves.....	
10.4, 10.6, 10.8, 10.10, 10.12, 10.13A, 10.13C, 10.14, 10.16, 10.18, 10.20 10.22, 10.24, 10.26, 10.28, 10.30, 10.32, 10.34, 10.36, 10.38, 10.40, 10.41, 10.42, 10.44-10.49, 10.53-10.54	
Nut, Copper Flare .....	6A.8, 6.8, 7.23, 8B.8, 8C.7, 8D.16
Nut, Mueller 110® Compression Connection .....	
5.12, 6A.7, 6.12, 6.31, 7.21, 8A.50, 8B.9, 8C.8, 8D.17	
Operating Nut, Tamper Proof.....	9A.6
Ori-Corp® Valves.....	5.7
O-Ring Conversion Kits (for Double Disc Gate Valve) ...	10.51
O-Rings, Mueller Insta-Tite® Connection .....	
6.18, 7.24, 8A.52, 8D.15	
Pack Joint Connections, Corporation Valves.....	
5.4, 5.7, 5.8, 6A.2	
"    "    "    , Check Valves .....	8B.5, 8D.14
"    "    "    , Couplings.....	
6A.5, 6A.6, 8B.6, 8E.1, 8E.2	
"    "    "    , Curb Valves.....	
6A.3, 7.7, 7.8, 7.12, 7.16	
"    "    "    , Meter Boxes, Iron.....	8C.1 - 8C.4
"    "    "    , Meter Valves .....	
8B.2 - 8B.4, 8D.1, 8D.2, 8D.4, 8D.5, 8D.9, 8D.11, 8D.12, 8D.14	
"    "    "    , Meter Yokes .....	
8A.3, 8A.5 - 8A.7, 8A.12, 8A.16, 8A.18, 8A.19	
"    "    "    , Service Fittings .....	6.13,-6.15
"    "    "    , Service Tees .....	6.24
"    "    "    , Service Valves .....	8D.12
"    "    "    , Tools/Equipment/Kits .....	
6.16, 6.32, 6A.7, 7.22, 8A.51, 8B.9, 8C.8, 8D.16	
"    "    "    , "U" & "Y" Branch Connections .....	
6.26, 6.27, 6.29	
Pentagon Key.....	8E.3
Pilot Drills.....	1.5, 1.13, 2.5, 2.10, 2.16, 3.4, 3.12
Pipe Beveling Tool.....	6.18, 7.24, 8A.52, 8C.9
Pipe Plugs .....	6.34
Pipe Reamer.....	6A.8, 6.80, 7.23, 8B.8, 8C.7, 8D.16
Pipe Removal Tool.....	6.18, 7.24, 8A.52, 8C.9, 8D.18
Pipe Repair Clamps .....	15.5-15.22
Pitometer Corporation Valves.....	5.11
Plugs, Brass .....	6.34
Plugs, Pipe .....	6.34
Position Indicator, Needle & Slot .....	10.50
Power Clevis, A-3™ Machine .....	1.16
"    "    "    B-101™ Machine .....	1.8
Power Operators .....	1.25, 2.13, 3.23, 3.24
Ratchet Handle Extension .....	1.8
Reamer, Pipe.....	6A.8, 6.7, 7.20, 8B.7, 8C.5, 8D.14

Rev. 4-14

Removal Tool, Pipe.....	6.17, 7.21, 8A.52, 8C.7, 8D.16
Relocator Copper Meter Yokes.....	8A.26-8A.28
Repair Clamps, Bell Joint.....	15.4
Repair Clamps, Pipe.....	15.5-15.24
Repair Lids, Curb Box.....	7.32
Repair Kits, Fire Hydrants.....	9.5, 9.11, 9.15, 9.19
Repair Sleeves, Split.....	12.11, 12.13
Resilient Seat Gate Valves (parts only).....	10.54
Resilient Wedge Gate Valves.....	10.4-10.43
Ribbed Insert Connections.....	6.21
Rods, Shut-off.....	7.31
Rollers, Tracks and Scrapers.....	10.51
Round Link Chains B-101™.....	1.3
“ ” “ H-W™.....	1.23
“ ” “ J™.....	1.19
Saddles, Machine A-3™.....	1.15
“ ” B-101™.....	1.7
Saddles, Service.....	4.4-4.14
Safety Flange Repair Kit.....	9.11, 9.15, 9.19
Screws, Curb Box for Lids.....	7.32
Screw Plugs, Tapered.....	15.24
Sealing Device for Lockwing Stops.....	8E.4
Seat Wrench for Fire Hydrants.....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27
Service Fittings...6A.5, 6.4 - 6.7, 6.9 - 6.11, 6.13 - 6.15, 6.17, 6.19 - 6.23	
Service Valves.....	8D.3, 8D.6, 8D.7, 8D.8, 8.12
Service Saddles.....	4.4 - 4.14
Service Tee.....	6.24-6.25
Shut-off Keys and Rods, Curb Box.....	7.31
Sleeve, Brass, for Fire Hydrants.....	9.10, 9.14, 9.18
Sleeve, Curb Box.....	7.32
Sleeves, Cut—In.....	12.23
Sleeves, Split Repair.....	12.10, 12.11
Sleeves, Tapping.....	12.2 - 12.7, 12.10
Solid Tee Head Curb Stops/Valves.....	7.18
Split Repair Sleeve.....	12.10, 12.11
Spreader, Chain.....	1.8, 1.16, 1.21, 1.23
Spur Gearing, Gate Valves.....	10.46
Stops, Angle Meter.....	8D.1, 8D.2, 8D.11, 8D.12, 8D.14
“ ” , Ground Key.....	5.8-5.11
“ ” , Ori-Corp®.....	5.7
Valves, Curb, Ball.....	7.5-7.10
“ ” , Bronze Gate.....	7.19
“ ” , Handles.....	7.19, 8D.20
“ ” , Inverted Key.....	7.18
“ ” , Oriseal®.....	7.11-7.17
“ ” , Solid Tee Head.....	7.18
Stops/Valves, Meter.....	8D.1, 8D.2, 8D.4, 8D.5, 8D.9 - 8D.12
Straight Line Inlet & Outlet Copper Meter Yokes.....	8A.20, 22
Tamper-Proof Accessories.....	9A.7
Tandem Copper Meter Yokes.....	8A.31
Tap, By-Pass Clean-Out, A-3™.....	1.16
Tapered Screw Plugs.....	15.24
Tapping Machines A-3™.....	1.11
“ ” B-101™.....	1.3
“ ” H-W™.....	1.23
“ ” J™.....	1.19
Tapping Crosses.....	12.8, 12.9
Tapping Sleeves.....	12.2-12.7
Tapping Valves.....	12.12 - 12.15, 12.18 - 12.20
Taps, Combined Drill and.....	1.4, 1.5, 1.12, 1.13, 1.20, 1.23
Taps, Combined Shell Cutter and, A-3™.....	1.13
“ ” “ ” “ , B-101™.....	1.5
Tees.....	6.24-6.25
Tools, Extracting A-3™.....	1.14
“ ” B-101™.....	1.6
Tools, Inserting A-3™.....	1.14
“ ” B-101™.....	1.6
Tru-Cut™ Drilling Machine.....	2.19
“U” Branch Connections.....	6.26-6.27
Valves, Angle Meter.....	8D.1, 8D.2, 8D.11, 8D.12, 8D.14
Valves, AWWA Check.....	13.2-13.11
Valves, AWWA Gate.....	10.4-10.45
Valves, Butterfly.....	11.3-11.16
Valves, By-Pass for Gate Valves.....	10.40-10.45
Valves, Corporation.....	5.4 - 5.11, 6A.2
Valves, Cut-In.....	12.24, 12.25
Valves, Inserting.....	12.22
Valves, Meter.....	8D.1, 8D.2, 8D.4, 8D.5, 8D.9 - 8D.12
Valves, Service.....	8D.3, 8D.6, 8D.7, 8D.8, 8.12
Valves, Tapping.....	12.12-12.15, 12.18-12.20
Vertical Check Valves.....	8A.1 - 8A.30, 8D.14
Vertical Inlet and Outlet Copper Meter Yokes.....	8A.10-8A.14, 8A.24, 8A.25
Washers, Adapter.....	2.5, 2.10, 2.16, 2.20, 2.23
Washers, Iron Meter Bars.....	8B.1
Washers, Meter Couplings.....	8E.4
Water Meter Bushings.....	8E.4
Water Meter Couplings.....	8E.1, 2
Water Meter Increaser.....	8E.4
Water Meter Iron Bars.....	8B.1
Water Meter Yokes.....	8A.1-8A.35
Web Belt, A-3™.....	1.16
“ ” B-101™.....	1.8
Wet Barrel Fire Hydrant (parts only).....	9.34
Wrenches, Corporation Stop/Valve.....	1.8, 16, 21, 23
Wrenches, Multiple for Meter Box Covers.....	8E.3
Wrenches, Operating for Fire Hydrants.....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27
Wrenches, Seat for Fire Hydrants.....	9.10, 9.14, 9.18, 9.22, 9.25, 9.27
“Y” Branch Connections.....	6.29-6.30