



Power clevis

CATALOG NUMBER: H-10802—The power clevis is used when making taps in mains having pressure over 90 psig (620 kPa). By its use, the boring bar can be forced down and a connection made against pressures as high as 250 psig (1723 kPa). The power clevis also permits controlled withdrawal of the boring bar to prevent damage to the tool threads and shock to machine.



Ratchet handle extension

PART NUMBER: 500684—When making cuts over 1" in size, this bar increases length of ratchet handle from 18-11/32" (466 mm) to 30-11/32" (771 mm). This permits greater leverage and ease of operation.



Corporation stop wrench

CATALOG NUMBER: H-10048—Used to operate 3/4" and 1" corporation stops.



Web belt

PART NUMBER: 88693—for pipe O.D. up to 12"
 PART NUMBER: 89119—for pipe O.D. up to 16"
 PART NUMBER: 580874—for pipe O.D. up to 36" Web belt replaces round or flat link chains to protect wrapped, coated or plastic pipes.



Round link extension chain

Round link extension chain

PART NUMBER: 80000—4' (1.2m) extension chain increases 12" (305mm) chain to fit 12"-24" pipe.
 PART NUMBER: 80001—6' (1.8m) extension chain increases 12" (305mm) chain to fit 12"-36" pipe.
 PART NUMBER: 87673—10' (3.0m) extension chain increases 12" (305mm) chain to fit 12"-48" pipe.



Flat link chain with eye bolt and nut

Flat link chain with eyebolt and nut

PART NUMBER: 580551—For pipe up to 12".



Flat link extension chain with bolts and nuts

Flat link extension chain with bolts and nuts

PART NUMBER: 89059—4' (1.2m) extension chain increases 12" (305mm) chain to fit 12"-24" pipe.
 PART NUMBER: 88126—6' (1.8m) extension chain increases 12" (305mm) chain to fit 12"-36" pipe.
 PART NUMBER: 88127—10' (3.0m) extension chain increases 12" (305mm) chain to fit 12"-48" pipe.



Flat chain hook with nut

PART NUMBER: 580550
 Chain hook with nut.



Chain spreader

PART NUMBER: 40321
 Used when tapping 3" or smaller pipe.