

## MUELLER / Hunt EZ-VAULT Meter Setter ordering instructions

To order a MUELLER / Hunt EZ-VAULT Meter Setter, simply choose the options you require from the seven categories listed below and place the option code on the appropriate line of the catalog number shown below.

If you require options not listed, please fill out the information box shown below the options listing and contact the factory for price and delivery information.

Phone 1-800-821-3553 or fax 1-615-895-7686.

### Catalog number

(1) \_\_\_\_\_ (2) \_\_\_\_\_ (3) \_\_\_\_\_ (4) \_\_\_\_\_ (5) \_\_\_\_\_ (6) \_\_\_\_\_ (7) \_\_\_\_\_

#### 1 Meter Size

NOTE: Meter is **not furnished**

Order meter separately.

Meter size	Code number
1-1/2"	500
2"	550

#### 5 Meter inlet type

Meter inlet	Code number
Flanged lockwing angle meter stop	L
Flanged lockwing angle ball valve (full port)	F

#### 2 Box style

Box style	Code number
Single meter	VS
Single meter with by-pass	VB

#### 6 Meter outlet type

Meter outlet	Code number
Flanged meter coupling	A
Flanged dual check valve	B
Flanged lockwing angle stop meter	L
Flanged lockwing angle ball valve (full port)	F

#### 3 Box diameter

Box diameter	Code number
<b>24" box is for use with:</b> 1-1/2" single flanged meter with or without by-pass	24
<b>27" box is used with:</b> 2" single flanged meter with or without by-pass	27

#### 7 Box bottom type

Bottom type	Code number
Attached aluminum bottom	A
Less bottom	B

#### 4 Box depth

Depth	Code number	Depth	Code number
30"	30	48"	48
36"	36	54"	54
42"	42	60"	60

### Special requirements order information

Please specify special requirements and include drawing or photo if possible:

---



---



---



---



---