


Fire Hydrant Parts List




Catalog Number	Description
1	Hydrant body
2	Nozzle insert
3	Hose cap
4	Hydrant stem
5	Stem locknut
6*	Beveled hydrant disc
7*	Hydrant disc locknut
8	Stem insert
9	Pent nut
10	Pent nut retainer
11*	Hydrant disc holder
12	Nozzle gasket
13	Nozzle insert O-ring
14	Stem insert O-rings
15*	Locknut retainer pin
16	Stem locknut retainer screw
17	Stem seal O-rings
18	Chain ring
19	Chain


* These parts are only available as a single assembly (valve assembly)

TO ORDER PARTS, SPECIFY THE FOLLOWING:

Quantity, part number and name, size and catalog number of hydrant, and direction of opening.



Standard Model



Monitor Model



International Division
6125 Preservation Drive, Suite 200
Chattanooga, TN37416 USA
www.mueller-international.com

UK Office : +44 1438 487410
Dubai Office: +971 4 214 6640
Singapore Office: +65 6631 8999
International@muellercompany.com