



Reliable Connections™

**H-603 Electric
Power Operator**

Operation Warning

To help prevent electrical shock or possible electrocution, always use the supplied Ground Fault Current Interrupter (GFCI) in series with this unit and a 3-prong grounding type receptacle, which is installed in accordance with the National Electrical Code. The GFCI is for use only with 120V, 60Hz Alternating Current (AC).

DO NOT use the GFCI on Direct Current (DC).

See instructions supplied with the GFCI for additional information. Extension cords must have a continuous rated capacity of 10 AMPS at 120 volts and include a properly connected grounding circuit.

DO NOT connect the ground wire (normally green) to the neutral wire (normally white).

DO NOT remove or in any way disable the grounding lug on the plus of the unit or GFCI.

Mueller H-603 Electric Power Operator should not be used in or near an explosive atmosphere such as, but not limited to, the presence of natural gas, sewer gas, etc., due to possibility of ignition by internal sparking from the Electric Motor Switch.

Phone: (800) 423-1323

By deviating from the above listed instructions, you will void any product warranty and release Mueller Co. and its affiliated entities from any and all liability associated with the installation or use of this product. For details on the product's warranty, terms, and conditions, please visit www.muellercompany.com.

© 2016 Mueller Co., LLC. All rights reserved.

Form 8933 06/16