

# SMART Flushing System IP Address - Setup Instructions


## General Description

- 1 The Hydro-Guard™ Remote Pressure Monitoring System is shipped with a factory-set IP address which can be changed as needed for customer installations.
- 2 The Factory-set (default) IP address is **192.168.001.099**.
- 3 To change the IP address to work best with your network, you must first gain access to the Graphical User Interface (GUI) of the PLC through this default IP address.
- 4 This access must be performed at the unit by attaching a PC, tablet, or similar device which can access the unit via an Ethernet cable.



## IP Address Setup Instructions

- 1 Connect to the PLC from a laptop using an Ethernet cable (crossover cable not required; you can use a network patch cable).
- 2 Change your LAN network adapter settings on the laptop to connect to the **192.168.001.099** address.
- 3 Once connection is established, navigate to **192.168.001.099** in your web browser.
- 4 Click on the "Comms" Tab.
- 5 Change the current IP address in the field to the desired IP address for the customer network, and click "Set IP".
- 6 Power down the breakers in the PLC unit.
- 7 Unplug the patch cable from the laptop and the PLC (leaving all cable connections unplugged).
- 8 After 15 seconds, power the PLC unit breakers back on.
- 9 Wait another 15 seconds for the PLC to re-initialize.
- 10 Plug in the customer network cable to the PLC.
- 11 The PLC unit should now be accessible at the new IP address.
- 12 If any problems are encountered, contact Product Support at **(423) 339-3982**.



**HYDRO-GUARD™**

**Mueller Co., LLC**  
633 Chestnut St., Suite 1200  
Chattanooga, TN 37450  
www.muellercompany.com  
moreinfo@muellercompany.com

Toll Free: 1.800.423.1323  
Canada: 1.705.719.9965  
International: 1.423.490.9555

Copyright © 2017 Mueller Co., LLC. All Rights Reserved.

The trademarks, logos and service marks displayed in this document herein are the property of Mueller Co., LLC, its affiliates or other third parties. These products are intended for use in potable water applications. Please contact your Mueller Sales or Customer Service Representative concerning any other application(s).

**Form 13721 - Rev 5/17**